

# Upper Horizontal Bookcase



## Tools Needed

- Power screwdriver with a Phillips #2 medium head bit.

## Optional Items

- Sandpaper.
- Wood glue.
- Paint

## Notes

Setup takes roughly 1 hour. It is easiest if you have two people doing it. If you are not sure how to install a piece always refer back to the picture above to see how everything fits together. Please read through the entire instructions to familiarize yourself first before beginning assembly.

Pilot holes have been predrilled into all necessary pieces.

You may want to add soap to the screws, the soap acts as a lubricant and makes driving them into the wood easier.

## Step One



Attach 2 Bookshelf post (2 x 6 x 18") to the Top of the Back Legs With 2-1/2" Black Course Screws. Connect with Two post connectors 2 x 6.

## Step Two



Place the Shelf Support (2 x 4) flat on top of the Bookcase post and screw on tight with 2-1/2" Black Course Screws into the new post extension support installed in step above.

### Step Three



Place the bottom shelf (3/4" x 7" x 79" Ply Board) (Note: For Queen Size and Extra Long it will be 80". For Dorm XXL It will be 84") on top of the (2x4) shelf support installed in above step. Screw the Ply shelf into the (2x4) support on tight with the Black 1-5/8" Course Screws.

## Step Four



Screw the side pieces (3/4" x 8-1/2" x 12-3/4" Ply) with 1-5/8" Black Course Screws into the side of the Ply Shelf installed in above step.

## Step Five



Place the Two (3/4" x 7" x 11-34") Center dividers in place and screw from under the Horizontal Ply installed in step above. Use the Black 1-5/8 Course Screws.

## Step Six



Rest the Top Ply shelf (3/4" x 7" x 80") (Note: will be longer for Queen Size, Extra Long and Dorm Extra Long) with Black 1-5/8" Course Screws.

## **Step Seven**

Place the Back Masonite Board (1/8" x 13" x 72-1/2") (Note: It will be Longer for the Queen Size, Extra Long and Dorm XXL) on the back and screw tight with the Black 1-5/8" Course Screws.

### **Parts:**

**2- Post Extensions 2" x 6" x 18"**

**2- Post Extension Connectors 2" x 6"**

**1- Shelf Support 2" x 4" x 79" (Longer for Queen Size, Extra Long or Dorm XXL)**

**1- Bottom Shelf Ply 3/4" x 7" x 79" (Longer for Queen Size, Extra Long or Dorm XXL)**

**2- End Side Ply Pieces 3/4" x 8-1/2" x 12-3/4"**

**2- Center Dividers 3/4" x 7" x 11-3/4"**

**1- Top Shelf 3/4" x 7" x 80" (Longer for Queen Size, Extra Long or Dorm XXL)**

**1- Back Masonite Panel Piece 1/8" x 13" x 67-1/2" (Longer for Queen Size, Extra Long or Dorm XXL)**

**16- Black Course 2-1/2" Screws**

**30- Black Course 1-5/8" Screws**