

Staircase Assembly Instructions

The Instruction Below Is For The Twin Size.
The Parts List For All Of The Sizes Scroll
Down Below.



Tools Needed

- Power screwdriver with a Phillips #2 medium head bit.

Optional Items

- Sandpaper.
- Wood glue.
- Paint

Notes

Setup takes roughly 1 hour. It is easiest if you have two people doing it. If you are not sure how to install a piece always refer back to the picture above to see how everything fits together. Please read through the entire instructions to familiarize yourself first before beginning assembly.

The wood used in your loft will typically have a (good) side and a (bad) side. The bad side will usually have a lumber grading stamp or some imperfections. Before assembly lay all the pieces out on the floor and try to position the wood with the “good” side facing up or out. Take into consideration which side you usually will be climbing up on and place the best rungs and legs on that side.

Pilot holes have been predrilled into all necessary pieces.

You may want to add soap to the screws, the soap acts as a lubricant and makes driving them into the wood easier.

Step One



Lay the 2" x 12" x 44" On Edge, As Shown In The Image. Place the 2" x 12 x 19-1/2" Top Shelf On Top Of The 2" x 12" x 44". That Is On Edge. Drill The Screws In To The Wood, Nice And Tight.

Step Two



Place The 2" x 12" x 9-1/2" Under The Top Shelf. Drill And Screw Nice And Tight.

Step Three



Place The 2" x 12" x 26-5/8" Under The 2" x 12" x 9-1/2". Screw On Too The Size Of The 2" x 12" x 44" As Well.

Step Four



Place The 2" x 12" x 35-1/2" Under The 2" x 12" x 9-1/2". Screw Nice And Tight And Screw On Too The Size Of The 2" x 12" x 44" As Well.

Step Five



Place The 2" x 12" x 44" Under The 2" x 12" x 9-1/2" Screw Nice And Tight And Screw On To The Size Of The 2" x 12" x 44" As Well. Place the Bottom Shelf On The 2" x 12" x 44" Under The 2" x 12" x 9-1/2" And Screw On To The Side Of The Size Of The 2" x 12" x 44" As Well.

Included In This Shipment

For Twin Size:
3-44" Wide 2"x12"
1-33" Wide 2"x12"
1-22" Wide 2"x12"
1-11" Wide 2"x12"
4-9-1/2" Wide 2"x12"

For Full Size:
1-55" Wide 2"x12"
2-59" Wide 2"x12"
1-48" Wide 2"x12"
1-37" Wide 2"x12"
1-26" Wide 2"x12"
1-15" Wide 2"x12"
5-9-1/2" Wide 2"x12"
6-9-1/2" Wide 2"x12"

For Queen Size:
1-66" Wide 2"x12"
2-65" Wide 2"x12"
1-55" Wide 2"x12"
1-44" Wide 2"x12"
1-33" Wide 2"x12"
1-22" Wide 2"x12"
1-11" Wide 2"x12"

—

(40) Pieces Of 2-1/2" Dry Wall Screws

(1) Set Of Instructions

Additional Pictures For Reference

